


39 DY-90959301 Wheel
40 DY-90788105 Switch button
41 DY-90118107 Switch
42 DY-90895010 Catch
43 DY-90735001 Switch cover
44 DY-90886801 Duct filter
45 DY-90886901 Exhaust seal
46 DY-90641601 Clip
47 DY-90749001 Inlet seal
48 DY-90747401 Valve pipe
49 DY-90746701 Retainer clip
50 DY-90747301 Cuff valve
51 DY-90747201 Valve seal
52 DY-90954601 Valve
53 DY-91389301 Spring assembly
54 DY-91389301 Spring assembly
55 DY-90856601 Cover
56 DY-91052201 Actuator
57 DY-91052201 Actuator
58 DY-90852601 Upright sw
59 DY-90810302 Loom switch
60 DY-90748801 Cover seal
61 DY-90748701 Duct cover
62 DY-90930001 Spring
63 DY-90746601 Stabiliser
64 DY-90827401 Stab axle
65 DY-90746301 Stab wheel
66 DY-90792801 Pedal
67 DY-90746201 Axlestand
68 DY-90053401 Washer
69 DY-90971303 Circlip
70 DY-90753401 Lower winder





71 DY-90814902 Int cable
72 DY-90019906 Spring
73 DY-90961402 Duct asy
74 DY-90867601 Power cord
75 DY-90118106 On off switch
76 DY-90788201 Switch button
77 DY-90749201 Valve seal
78 DY-90020019 Screw
79 DY-90951201 Pcb
108 DY-90019987 Spring
118 DY-90806201 Boot




1 DY-90731401 Yoke
2 DY-90859401 Hose
3 DY-90731501 Guard hose
4 DY-90731601 Clip
5 DY-90997202 Motor cover
7 DY-90743902 Cover
8 DY-90954801 End cap r
9 DY-90735601 Motor mount
10 DY-90929901 Bumper
11 DY-90743601 Bumper 1
12 DY-90998402 Lock arm
13 DY-90955702 Yoke assy
14 DY-90731301 Yoke brkt
15 DY-90019985 Spring
16 DY-90020007 Screw
18 DY-90731101 Yoke cover
19 DY-90897801 Clip
20 DY-90019988 Spring
21 DY-91070301 Screw
22 DY-90959402 Yoke loom
23 DY-90728002 Loom
24 DY-90961702 Motor
25 DY-90735301 End motor
27 DY-90797903 Housing
28 DY-90954901 End cap
29 DY-90013004 Fastener
30 DY-90959205 Brush bar
31 DY-90912402 Wheel
32 DY-90013101 Axle
33 DY-90961502 Soleplate
34 DY-90961502 Soleplate
35 DY-90020024 Screw

36 DY-91070210 Screw

38 DY-90020006 Screws



90 DY-90865813 Cyclone
91 DY-90848301 Filter
92 DY-90739901 Seal
93 DY-90865702 Bin
94 DY-90900101 Bin base
96 DY-91047102 Filter
98 DY-90804301 Brush tool
99 DY-90803801 Crevice tool
100 DY-90804401 Stair tool
102 DY-90822505 Wand cap
105 DY-90954402 Handle
106 DY-90954506 Hose
107 DY-90732301 Ubend seal
120 DY-90955302 Instruction



80 DY-90961601 Motor bucket
81 DY-90959602 Loom seal
82 DY-90176803 Bearing
83 DY-90726301 Bucket axle
84 DY-90727101 Motor mount
85 DY-90956302 Motor
86 DY-90727201 Case seal
87 DY-90726201 Bearing
88 DY-90957701 Ball
89 DY-90020018 Screw